

INSTRUCTION MANUAL

THERMAL MASS FLOW METER

MODEL : KC-2600 Series



Gas & Liquid type

■ Insertion type



■ Inline type



Smart valley A-1805, SONGDO MIRAE-RO30,
Yeonsu-gu, Incheon, Korea

TEL:+82-32-817-1240

FAX:+82-32-817-1250

E-mail:hmm617@hanmail.net

<http://www.goldenrules.co.kr>



Chapter 1 Introduction

Warnings and Cautions	1
Series KC-2600Series Smart-INTM Thermal Mass Flow Meters	2
Using this Manual	2
Note and Safety Information	3
Receipt of System Components	3
Technical Assistance	3
The Series KC-2600Series Flow Sensing Principle	4

Chapter 2 Installation and Wiring

Installation Overview	5
Unobstructed Flow Requirements	6
Installing the Flow Meter	7
Cold Tap Installation	7
Hot Tap Installation	8
Calculating Insertion Depth for a Low Pressure Tap	9
Calculating Insertion Depth for a High Pressure Tap	10
Wiring Connections	11
AC / DC Input Power & Output Signal Wiring	11

Chapter 3 Operating Instructions

How to Operate	12
1) Status LED & Front side-up Key	12
2) Indication window of measured value	13
3) How to reset total count accumulated value	13
How to Set Parameters	14~16
Explanation of parameter set-up Mode	16~19
KC-2600 Protocol MAP	19~23

Chapter 4 Troubleshooting and Repair

Troubleshooting the Flow Meter	24
GAS FACTOR TABLE	25~28

Warnings and Cautions

Warnings and Cautions



Warning! Agency approval for hazardous location installations varies between flow meter models. Consult the flow meter nameplate for specific flow meter approvals before any hazardous location installation.

Warning! Hot tapping must be performed by a trained professional. U.S. regulations often require a hot tap permit.

The manufacturer of the hot tap equipment and/or the contractor performing the hot tap is responsible for providing proof of such a permit

Warning! All wiring procedures must be performed with the power Off.

Warning! To avoid potential electric shock, follow National Electric Code safety practices or your local code when wiring this unit to a power source and to peripheral devices.

Failure to do so could result in injury or death.

All AC power connections must be in accordance with published CE directives.

Warning! Do not power the flow meter with the sensor jumper wires disconnected.

This could cause over-heating of the sensors and/or damage to the electronics.

Warning! Before attempting any flow meter repair, verify that the line is de-pressurized.

Warning! Always remove main power before disassembling any part of the mass flow meter.



Caution! Before making adjustments to the Smart Electronics device, verify the flow meter is not actively monitoring or reporting to any master control system. Adjustments to the electronics will cause direct changes to flow control settings.

Caution! All flow meter connections, isolation valves and fittings for hot tapping must have the same or higher pressure rating as the main pipeline.

Caution! Changing the length of cables or interchanging sensors or sensor wiring will affect the accuracy of the flow meter. You cannot add or subtract wire length without returning the meter to the factory for re-calibration.

Caution! When using toxic or corrosive gases, purge the line with inert gas for a minimum of four hours at full gas flow before installing the meter.

Caution! The AC wire insulation temperature rating must meet or exceed 71°C (158°F).

Caution! Printed circuit boards are sensitive to electrostatic discharge. To avoid damaging the board, follow these precautions to minimize the risk of damage :

- before handling the assembly, discharge your body by touching a grounded, metal object
- handle all cards by their edges unless otherwise required
- when possible, use grounded electrostatic discharge wrist straps when handling sensitive components

Series KC-2600 Smart-Programmable Thermal Mass Flow Meters

Golden Rules Series KC-2600 Smart Insertion Thermal Mass Flow Meter provides a reliable solution for gas and liquid flow measurement applications.

Low-flow sensitivity, fast response and outstanding range ability have made this model the instrument of choice for many critical gas and liquid flow applications.

For stable and reliable mass flow reading, the meter's rugged Smart-IN™ sensor automatically corrects for changes in gas temperature and pressure which eliminates the need for separate temperature and pressure transducers.

The versatile microprocessor-based transmitter integrates the functions of flow-range adjustment, meter validation and diagnostics in a probe-mounted or remotely-mounted housing. Mass flow rate and totalized flow, as well as other configuration variables are displayed on the meter's optional 2 x 16 LCD display.

The gauge indicates output, pulse and electric current. The programmable transmitter is easily configured via RS-485 and Golden Rules Smart Interface software or through three push buttons built into the device.

The Series KC-2600 is suitable for insertion into pipes or ducts from three inches up to 72 inches.

The Series KC-2600 Thermal Mass Flow Meter's simple installation combines with an easy-to-use interface that provides quick set up, long term reliability and accurate mass flow measurement over a wide range of flows and conditions.

Using This Manual

This manual provides information needed to install and operate the Series KC-2600 Smart Insertion Thermal Mass Flow Meter.

The four chapters of this manual cover these areas :

- Chapter 1 includes the introduction and product description
- Chapter 2 provides installation and wiring instructions
- Chapter 3 describes system operation and programming
- Chapter 4 covers troubleshooting and repair

The product specifications are found in Appendix A.

We use caution and warning statements throughout this book to draw your attention to important information.



This statement appears with information that is important to protect people and equipment from damage. Pay very close attention to all warnings that apply to your application.



This statement appears with information that is important for protecting your equipment and performance. Read and follow all cautions that apply to your application.

Receipt of System Components

When receiving a Golden Rules Thermal mass flow meter, carefully check the outside packing carton for damage incurred in shipment.

If the carton is damaged, notify the local carrier and submit a report to the factory or distributor.

Remove the packing slip and check that all ordered components are present. Make sure any spare parts or accessories are not discarded with the packing material.

Do not return any equipment to the factory without first contacting Golden Rules Customer Service.

Technical Assistance

If you encounter a problem with your flow meter, review the configuration information for each step of the installation, operation and setup procedures.

Verify that your settings and adjustments are consistent with factory recommendations.

Refer to Chapter 4, Troubleshooting, for specific information and recommendations.

If the problem persists after following the troubleshooting procedures outlined in Chapter 4, contact Golden Rules by fax or by E-mail (see inside front cover).

For urgent phone support you may call (+82) 032-817-1240 between 09:00 a.m. and 18:00p.m.PST.

When contacting Technical Support, make sure to include this information :

- The flow range, serial number and Golden Rules order number (All marked on the meter nameplate)
- The software version (Visible at start up)
- The problem you are encountering and any corrective action taken
- Application information (Gas, liquid, Pressure, Temperature and piping configuration)

The Series KC-2600 Principle of Flow Sensing



KC-2600 Series
Thermal Mass sensor

The Mass flow probe, proper to Golden Rules ensures the excellent accuracy, strength and reliability of the industrial flowmeter.

In the Mass flow sensor, if it's composed of two sensing parts, one is a flow velocity sensor, and the other temperature sensor that automatically corrects according to the change of gas or liquid Temperature.

the new element consists of two temperature platinum resistors in one chip. while high ohm resistor is used to measure the base temperature, the low ohm resistor is used as heater. By using the bridge circuit, each different resistance value of two elements and each different self-heat are produced. The self-heat depends on the supply voltage, mass flow, medium where the sensor is placed, the high voltage increases the self-heat, and the higher flux increases the cooling. If the self-heat is continued by appropriate controller, the mass flow can be measured as the voltage will increase with high flow rate.

Installation Overview

The Series KC-2600 flow meter is factory calibrated to the specific pipe size shown on the meter's Certificate of Calibration. The factory Calibration eliminates the task of calculating the average flow across the pipe to determine the correct insertion depth. Simply insert the flow meter sensor to the centerline position of the pipe.

(If the pipe size differs from the meter's calibrated size, return the meter to the factory for re-calibration.)

When selecting an installation site, make sure that :

1. Line pressure and temperature will not exceed the flow meter rating. Temperature should not vary more than 100°C (200°F) around the calibration temperature. Line pressure should not vary more than 50 psi (3.4 bar) around the calibrated pressure.
2. The location meets the required minimum number of pipe diameters upstream and downstream of the sensor head (see Figure 2-1 on the next page).
3. Safe and convenient access with adequate clearance. Also, verify the meter is located where the gas is clean and dry and the meter is calibrated for the gas to be measured.
4. When using a CSA, FM or Ex approved flow meter, verify that the cable entry into the instrument meets the specific standard required for that approval.
5. For remote installations, verify the supplied cable length is sufficient to connect the flow meter sensor to the remote electronics.
(Do not extend or shorten the supplied cable between the probe and the electronics.)

Also, before installation check your flow system for anomalies such as :

- Leaks
- Valves or restrictions in the flow path that could create disturbances in the flow profile that might cause unexpected flow rate indications.
- Heaters that might cause rapid excursions in the measured temperature.



Warning!

Agency approval for

Hazardous location installations

Varies between flow meter models.

Consult the flow meter nameplate

for specific flow meter approvals

before any hazardous location

installation.

Unobstructed Flow Requirements

Unobstructed Flow Requirements

Select an installation site that will minimize possible distortion in the flow profile. Valves, elbows, control valves and other piping components may cause flow disturbances.

Check your specific piping condition against the examples shown below.

In order to achieve accurate and repeatable performance install the flow meter using the recommended number of straight run pipe diameters upstream and downstream of the sensor.




Figure 2-1. Recommended Pipe Length Requirements for Installation

Installing the Flow Meter

Installing the Flow Meter

When positioning the flow meter, refer to the flow direction indicator attached to the probe. For proper operation, install the meter with the flow direction indicator pointing downstream in the direction of flow.

Installing the meter opposite this direction will result in inaccurate flow measurement


Cold Tap Installation

1. Confirm that the installation site meets the minimum upstream and downstream pipe diameter requirements shown in Figure 2-1.
2. Turn off the flow of process gas. Verify that the line is not pressurized.
3. Use a cutting torch or sharp cutting tool to tap into the pipe. The pipe opening must be at least 0.88 inches in diameter. (Do not attempt to insert the sensor probe through a smaller hole.)
4. Remove all burrs from the tap. Rough edges may cause flow profile distortions that could affect flow meter accuracy. Also, obstructions could damage the sensor assembly when inserting into the pipe.
5. Mount the compression or flange fitting on the pipe. Make sure this connection is within $\pm 5^\circ$ perpendicular to the pipe centerline as shown at left.
6. When installed, cap the fitting. Run a static pressure check on the connection. If pressure loss or leaks are detected, repair the connection and re-test.
7. Insert the sensor probe through the compression or flange fitting into the pipe. The correct insertion depth places the sensor at the pipe's centerline. Do not force into the pipe.
8. Align the sensor head using the flow direction indicator. Adjust the indicator parallel to the pipe pointing downstream in the direction of flow.
9. Tighten the fitting to lock the flow meter in position. (When a compression fitting is tightened, the position is permanent unless using Teflon ferrules.)
10. If needed, adjust the optional display to the desired orientation.




Caution!

When using toxic or corrosive gases, purge the line with inert gas for a minimum of four hours at full gas flow before installing the flow meter.



Correct Alignment Incorrect Alignment





Hot Tap Installation

Hot Tap Installation

When positioning the flow meter, refer to the flow direction indicator attached to the probe. For proper operation, install the meter with the flow direction indicator pointing downstream in the direction of flow. Installing the meter opposite this direction will result in inaccurate flow measurement.

Low pressure hot taps cannot exceed 100 psig (7 barg) maximum.

High pressure hot taps cannot exceed 1000 psig (70 barg) maximum.

Make sure the pipe pressure does not exceed these limits before beginning this procedure.

1. Confirm that the installation site meets the minimum upstream and downstream pipe diameter requirements shown in Figure 2-1.
2. Calculate the flow meter insertion depth as shown in Figure 2-2 for a low pressure tap or Figure 2-3 for a high pressure tap.
3. Weld the process connection on the pipe.
Make sure the process connection is within $\pm 5^\circ$ perpendicular to the pipe centerline (see previous page).
The pipe opening must be at least 0.88 inches (22 mm) in diameter.
4. Bolt an isolation valve on the process connection. The valve's full open bore must be at least 0.88 inches (22 mm) in diameter.
5. Hot tap the pipe.
6. Close the isolation valve. Run a static pressure. If pressure loss or leaks are detected, repair the connection and re-test.
7. Insert the sensor probe through the isolation valve into the pipe with the flow direction indicator parallel to the pipe pointing downstream in the direction of flow. The correct insertion depth places the sensor at the pipe's centerline. Do not force into the pipe.
8. Tighten the fittings to lock the flow meter in position. If needed, adjust the optional display to the desired orientation.



Warning!

Hot tapping must be performed by a trained professional. U.S. regulations often require a hot tap permit. The manufacturer of the hot tap equipment and/or the contractor performing the hot tap is responsible for providing proof of such a permit.



Caution!

All flow meter connections, isolation valves and fittings for hot tapping must have the same or higher pressure rating as the main pipeline.

〈Calculating Insertion Depth for a Low Pressure Tap〉

Variables

L = Nominal probe length

D = Duct O.D.

C = Duct I.D.

T = Height of "Thread let" or customer provided "Weld let"

Formula

$$L \geq 12 + D/2 + T$$

L must be equal or greater than 12 inches plus the height of the "Thread let" plus half the duct O.D.
(All dimensions in inches.)




Figure 2-2. Low Pressure Tap Insertion Depth

〈Calculating Insertion Depth for a High Pressure Tap〉

Variables

S = Distance from face of mounting flange to outside of duct

D = Duct O.D.

P = Minimum probe length

T = Minimum probe travel

R = Allowable probe travel

IN = Inserted position (marker location)

RE = Retracted position (marker location)

Formulas

1) $P = D/2 + S + 6.75$ (minimum probe length—use next longer whole number length probe)

2) $T = D/2 + 0.54$

3) $R = 28.2 - [\text{actual probe length} - S - (D/2)]$ (must be greater than or equal to T)

4) $IN = (\text{actual probe length} + 2) - (5.5 + S + D/2)$

5) $RE = IN + T$

(All dimensions in inches.)




Figure 2-3. High Pressure Tap Insertion Depth

Wiring Connections

Wiring Connections

The KC-2600 enclosure type uses AC or DC terminals for power connections and uses 4-20mA OUT +,OUT- terminals for signal connection. To comply with all CE standard requirements use AC or DC connection method mentioned below

Standard type terminal block





Figure 2-4. Wiring Access KC-2600 Series Enclosure

Explosion-proff terminal block



1. P24V / AC100 ~ 240V : Power input terminal (When DC inputting +)
2. N24V / AC100 ~ 240V : Power input terminal (When DC inputting -)
3. RS485 + : When MOD-BUS RS485 communicates, DATA + terminal
4. RS485 - : When MOD -BUS RS485 communicates, DATA - terminal
5. OUT + : ANALOG 4~20 mA CURRENT + terminal
6. OUT - : ANALOG 4~20 mA CURRENT + terminal
7. PULSE + : PULSE Output + terminal
8. PULSE - : PULSE Output - terminal



Warning!

To avoid potential electrical shock, connect the phantom to power source or when connecting to any peripherals follow NEC safety guidelines or local regulations. If you fail to do so injury or death could follow. All power connections must be in accordance with CE regulatory guidelines.



Caution!

The AC wire insulation temperature rating must meet or exceed 71°C (158°F).



Warning!

All wiring procedures must be performed with the power Off.

Chapter 3 Operation

How to operate

This chapter handles how to program the flowmeter, and how to check the progress of the flowmeter. All the explanations on programming are going ahead watching the LCD window.




Figure 3-1. Smart Electronics DeviceLocations

How to use the basic specification

It explains how to do the basic input as follows.

1) State LED

PULSE : Lights on when Pulse output is on time

TXD : Data transmitting LED when RS485 communicates

RXD : Data receiving LED when RS485 communicates

MODE : Sensor-trouble sensing LED

(When there's trouble in sensor and inner sensor detection board, LED flickers)

Front side Set-up Key

MODE : Changes the set mode when setting parameter

◀ : Changes the place when setting parameter

▲ : Changes the value increase of set place when setting parameter


SET RST : Enters the mode or saves the set value when setting parameter

At normal state, use with total count reset key


2) Indication window of measured value

① NOMAL state

- a. If pressing once  or  key respectively, one can see by selecting the following 4 kinds of indication mode.
- b. Maximum value of data
- TOTAL COUNT accumulated value : 49999999999
 - Flow rate : 99999 - Flow velocity : 99.9m/s



② Set state of parameter



3) How to reset total count accumulated value

1) Reset by the front reset key()


- ① At normal state, if pressing  key for 3 seconds, **CNT RESET→** is displayed on LED window, at this time, if pressing  key once more, total count accumulated value is reset.
- ② **CNT RESET→** message is displayed for 3 seconds, but, reset is available only when pressing  key with this message displayed.


2) Reset by RS485 communication


- ① If transmitting 1 to MOD-BUS ADDRESS 40016, total count accumulated value is reset.

How to set up Parameter

: At normal state, if pressing  ,  keys at the same time, the current firmware version is displayed, and if opening the key, one can set up Parameter.







EXPLANATION OF PARAMETER SET-UP MODE

1) DECIMAL POINT MODE OF FLUX

- ① MODE that explains the decimal point of the indicated flux
- ② The available decimal points are X.X and X.

2, 3) LOW And High SCALE SET-UP MODE OF FLUX

- ① MODE that sets up the low full scale of flux
- ② The set range is 0.0 ~ 99999.
- ③ If changing HIGH SCALE value, the ANALOG output HIGH RANGE one is automatically changed to this value.

4) FLUX UNIT SET-UP MODE

- ① MODE that sets up the unit of indicated flux
- ② The available units are as follows :
L/h, L/m, L/s, cc/h, cc/m, cc/s, m³/h, m³/m, m³/s, Kg/h, Kg/m, Kg/s, NL/h, NL/m, NL/s, Ncc/h, Ncc/m, Ncc/s, Nm³/h, Nm³/m, Nm³/s, Nml/h, Nml/m, Nml/s, mL/h, mL/m, mL/s, Nm/h, Nm/m, Nm/s, Ton/h, Ton/m, Ton/s

5) FLUX CORRECTION FACTOR SET-UP BLANK MODE

- ① MODE that sets up the correction FACTOR, multiplied with multiplier value to the indicated flux
- ② The range is 0.001 ~ 999. 999, and the default value at factory is 1,000.

6) MEASURING TYPE SET-UP MODE

- ① MODE that selects the flux TYPE to measure.
- ② One can select one from GAS and WATER.

7) FLOW VELOCITY CORRECTION MODE BY FLOW VELOCITY LINEAR TABLE

- ① It's a mode, used to correct the indicated flow velocity only in a specific area.
- ② Linear table's factory value is off, and if changing to on, it's possible to correct by dividing up to 30m/s in 1m/sec.
- ③ If changing from off to on, TAB value and REV value are initialized to the same value, at this time, move to TAB area to correct, then, use by changing REV value.

8) RESPONSE-TIME SET UP MODE

- ① MODE that sets up the indicated response time

- ② The set range is 0.2 ~ 19.9 sec.
- ③ Default value at factory is 0.3 sec.

9) FLOW VELOCITY LOW CUT MODE


- ① If flow velocity is lower than the fixed value, make cutting and indicate with 0.0m/sec, then, don't accumulate total count.

10) PULSE OUTPUT DIVIDE SET-UP MODE

- ① MODE that sets up DIVIDE of PULSE output
- ② PULSE output COUNT value = TOTAL COUNT accumulated value / DIVIDE set value
- ③ Set range : 1, 10, 100, 1000
- ④ Factory default value is 1.

11) PULSE OUTPUT DUTY TIME SET-UP MODE

- ① As a mode that sets up on time of pulse output, output pulse ontime always turns on, and output during this set value.
- ② Set value : 10 ~ 9999msec. (10msec STEP)
- ③ Factory default value is 50 msec. appropriate value after checking the spec of the connected exterior meter.



12) TOTAL COUNT DECIMAL POINT SET-UP MODE

- ① MODE that sets up the decimal point of TOTAL COUNT accumulated value
- ② The available decimal points are X.X and X.

13) TOTAL COUNT DIVIDE SET-UP MODE

- ① MODE that sets up the DIVIDE value of TOTAL COUNT accumulated value
- ② TOTAL COUNT value : TOTAL COUNT calculation value / DIVIDE set-up value
- ③ Set area : 0.01, 0.1, 1, 10, 100, 1000
- ④ Factory default value is 1.

14) TOTAL COUNT SET-UP MODE

- ① MODE that sets up the TOTAL COUNT accumulated value with optional value.

15) TOTAL COUNT DISP TIME SET-UP MODE

- ① MODE that sets up the speed indicating TOTAL COUNT accumulated value on LCD window.
- ② Set area is 0.1 ~ 99.9 sec.
- ③ Factory default value is 1.0 sec.

16) ANALOG OUT LOW RANGE SET-UP MODE

- ① MODE that sets up the flux value for 4mA of ANALOG output 4 ~ 20 mA output
- ② Set area is 0.0 ~ 99999.
- ③ If changing flux LOW SCALE value, this set value is automatically changed to flux low scale value.
- ④ If changing this value, it's possible to set separately from LOW SCALE value of flux.

17) ANALOG OUT HIGH RANGE SET-UP MODE

- ① MODE that sets up the flux value for 20mA of ANALOG output 4~20 mA output
- ② Set range is 0.0 ~ 99999.
- ③ If changing the flux HIGH SCALE value, this set value is automatically changed to flux HIGH SCALE value.
- ④ If changing this value, it's possible to set separately from the flux HIGH SCALE value.

18) ANALOG OUT ZERO CORRECTION MODE

- ① MODE that corrects 4 mA of ANALOG output 4~20 mA.
- ② As it's released after correcting to 4.000mA at the factory, the use doesn't need to correct separately, but, if needing to correct at the actual site, one must correct by means of accurate DIGITAL MULTI METER.

19) ANALOG OUT SPAN CORRECTION MODE

- ① MODE that corrects 20mA of ANALOG output 4~20 mA
- ② As it's released after correcting to 20.000mA at the factory, the user doesn't need to correct separately, but, if needing to correct at the actual site, one must correct by means of accurate DIGITAL MULTI METER.

Thermal mass flow meter (KC-2600 series) Field current (4-20mA) adjustment method

I will show you how to adjust the current.

1. Press the MODE + UP + SET keys simultaneously.
2. Press the SHIFT key twice. If you press the UP key once, the password becomes 10. In this state, press the SET key
3. Press the MODE key to display the A-OUT ZE CAL menu and press SET.
4. Use the SHIFT and UP keys to set the 4mA precisely.
5. If the A-OUT SP CAL matches the 20mA output, if it is wrong Method.
6. When A-OUT TEST is displayed on the screen, press SET key and press UP key. 4mA at 0%, 8mA at 25% , At 50% 12mA , At 75% 16mA, check if At 100% 20mA, as correct.
7. Press MODE key to exit MODE END when SET is pressed.



20) ANALOG OUT TEST MODE

- ① MODE that can TEST the meter, connected to the output by randomly outputting ANALOG output 4~20mA with 0%(4 mA), 25%(8 mA), 50%(12 mA), 75%(16mA), 100%(20mA).

21) RS485 COMMUNICATION ADDRESS SET-UP MODE


- ① MODE that sets up the STATION when MOD-BUS RS485 communicates
- ② Set range : 1 ~ 255
- ③ Factory default value is 1.

22) RS-485 COMMUNICATION SPEED SET-UP MODE

- ① MODE that sets up the communication speed (BAUD RATE) when MOD-BUS RS485 communicates
- ② Set range : 2400BPS ~ 57600 BPS
- ③ Factory default value is 9600BPS

23) LINEAR TABLE CALCULATION VALUE-INDICATING MODE

- This MODE is displayed only when turned ON the LINEAR TABLE correction mode of 7), and one can see the flux value before and after correcting linear table.



KC-2600 PROTOCOL MAP

- ◆ INTERFACE : 2WIRE RS-485
- ◆ COMMUNICATION SPEED : 2400BPS ~ 57600 BPS
- ◆ COMMUNICATION ADDRESS : 1 ~ 255
- ◆ DATA LENGTH : 8 BIT
- ◆ PARITY : NONE PARITY
- ◆ STOP BIT : 1 STOP BIT
- ◆ PROTOCOL : MOD-BUS RTU SLAVE PROTOCOL
- ◆ FORMAT

1) KC-2600 DATA REQUEST FORMAT

KC-2600 ADDR	FUNCTION CODE	START ADDR HIGH	START ADDR LOW	CHANNEL H	CHANNEL L	CRC H	CRC L
1~255	04H or 03H	START ADDRESS		CHANNEL SIZE(n)		CRC16	



- a. REQUEST OF CURRENT FLUX, FLUX SPEED, TOTAL COUNT ACCUMULATED VALUE DATA
 - FUNCTION CODE : 04H (MOD-BUS MEMORY FUNCTION의 INPUT REGISTER 04H)
 - START ADDRESS : 0000H ~ 0008H (MOD-BUS ADDRESS 30000 ~ 30007)
 - CHANNEL SIZE : 0001H ~ 0008H
 - DATA CONTENT : Refer to article a of response format (DATA 0 ~ DATA 7)
- b. REQUEST FOR KC-2600 SET VALUE
 - FUNCTION CODE : 03H (MOD-BUS MEMORY FUNCTION의 HOLDING REGISTER 03H)
 - START ADDRESS : 0000H ~ 001AH (MOD-BUS ADDRESS 40001 ~ 40020)
 - CHANNEL SIZE : 0001H ~ 001AH
 - DATA CONTENT : Refer to article b of response format (DATA 0 ~ DATA 19)

2) KC-2600 RESPONSE FORMAT

ADDR	FUNCTION CODE	BYTE SIZE	DATA H	DATA L	DATA H	DATA L
1~255	04H or 03H	STARTADDR X2	DATA0		DATA1	

DATA H	DATA L	DATA H	DATA L	CRC H	CRC L
DATA _{n-1}		DATA _n		CRC16	

- a. CURRENT FLOW RATE, FLOW RATE, ACCUMULATED VALUE OF TOTAL COUNT RESPONSE TO DATA REQUEST (MOD-BUS ADDR 30000 ~ 30007)
 - FUNCTION CODE : 04H (INPUT register 04H of MOD-BUS MEMORY FUNCTION)
 - BYTE SIZE : DATA request CHANNEL SIZE X 2
 - DATA0, DATA1 (MOD-BUS ADDRESS (30000, 30001):THE CURREN FLOW BALUE
 - Use 2 words, and the calculation formula is the value of (Value of 30001X 65536) + 30000
 - It's 1 digit value with same to decimal point
 - DATA2 (MOD-BUS ADDRESS 30002: Unit of flow rate
 - Range is 0 ~ 32.
 - (Nm³/h : 0, Nm³/m : 1, Nm³/s : 2, Kg/h : 3, Kg/m : 4, Kg/s : 5, NL/h : 6, NL/m : 7, NL/s : 8, Ncc/h : 9, Ncc/m : 10, Ncc/s : 11, m³/h : 12, m³/m : 13, m³/s : 14, L/h : 15, L/m : 16, L/s : 17, cc/h : 18, cc/m : 19, cc/s : 20 NmL/h : 21, NmL/m : 22, NmL/s : 23, mL/h : 24, mL/m : 25, mL/S : 26, Nm/h : 27 Nm/min : 28, Nm/s : 29, TON/h : 30, TON/m : 31, TON/s : 32)
 - DATA 3 (MOD-BUS ADDRESS 30003: Current flow cate
 - The same decimal point is 1 digit and the unit is m/s



- DATA4, DATA5 (MOD-BUS ADDRESS 30004,30005 : Total count accumulated value
 - Using 2 word and the formula is (Value of 30005 × 65536) + 30004
 - The value is combined with the decimal point of DATA6(MOD-BUS ADDRESS30006 Ex) The value of DATA4. DATA5 is 123456 if value of DATA6 is 1 true accumulate value is TOTAL COUNT is 12345.6
 - DATA6(MOD-BUS ADDRESS 300006): TOTAL COUNT DECIMAL POINT OF CUMULATIVE VALUE
 - Range : 0 or 1 (0: no decimal point, 1: one decimal place)
 - DATA7 (MOD-BUS ADDRESS 30007) : When there's trouble in sensor and inner sensor detection board, transmit 1. (When sensor works normally, transmit 0)
- b. RESPONSE OF KC-2600 SET VALUE (MOD-BUS ADDRESS 40001 ~ 40020)
- FUNCTION CODE : 03H (Holding register 03H of MOD-BUS Memory function)
 - BYTE SIZE : Data request channel size X 2
 - For data content, refer to the format saving the set value change

3) FORMAT SAVING KC-2600 SET VALUE CHANGE (MOD-BUS ADDR 40001 ~ 40026)

◆ SAVE 1 WORD DATA

KC-2600 ADDR	FUNCTION CODE	ADDR H	ADDR L	DATA H	DATA L	CRC H	CRC L
1~255	06H	0000H ~ 0000DH		DATA0 ~ DATA15		CRC16	

- ALL PARAMETERSEXCEPT flux LOW SCALE, HIGH SCALE, analog OUT PUT LOW RANGE, HIGH RANGE, TOTAL COUNT accumulated value set-up parameter correspond to it.
- FUNCTION CODE : 06H (Holding register 0311 of MOD-BUS MEMORY FUNCTION)
- ADDR H,ADDR L : ADDRESS of set PARAMETER
 - ADDRESS 0000H becomes 400001(Data 0 value)
- DATA0 (MOD-BUS ADDRESS 40001) : Set decimal point of the current flux value
 - Range is 0 or 1 (0: no decimal point, 1 : one decimal place)
- DATA 1(MOD-BUS ADDRESS 40002) : Set the flux unit
 - Range is 0 ~ 32.
 - (Nm³/h : 0, Nm³/m : 1, Nm³/s : 2, Kg/h : 3, Kg/m : 4, Kg/s : 5, NL/h : 6, NL/m : 7, NL/s : 8, Ncc/h : 9, Ncc/m : 10, Ncc/s : 11, m³/h : 12, m³/m : 13, m³/s : 14, L/h : 15, L/m : 16, L/s : 17, cc/h : 18, cc/m : 19, cc/s : 20, NmL/h : 21, NmL/m : 22, NmL/s : 23, mL/h : 24, mL/m : 25, mL/S : 26, Nm/h : 27, Nm/min : 28, Nm/s : 29, TON/h : 30, TON/m : 31, TON/s : 32)
- DATA2 (MOD-BUS ADDRESS 40003) : Set up measuring type
 - It's possible to select between gas and water, and the range is 0, 1. (0: Gas, 1: Water)



- DATA3 (MOD-BUS ADDRESS 40004) : Set flow velocity low cut
 - The range is 0.0m/s ~ 99.9m/sec, and one should multiply 10 when transmitting the value.
- DATA4 (MOD-BUS ADDRESS 40005) : Set response time
 - Range is 0.1 ~ 99.9 sec., and when transmitting the value, one should send by multiplying 10.
- DATA 5 (MOD-BUS ADDRESS 40006) : Set the pulse output divide value
 - Range is 0 ~ 3. (0:1, 1:10, 2:100, 3:1000)
- DATA 6 (MOD-BUS ADDRESS 40007) Set Pulse output duty
 - Range is 10 ~ 9999msec., and possible to set by 10msec step.
- DATA 7 (MOD-BUS ADDRESS 40008) : Decimal point of total count accumulated value
 - Range is 0 or 1. (0 : no decimal point, 1: one decimal place)
- DATA 8 (MOD-BUS ADDRESS 40009) : Set Divide of total count accumulated value
 - Range is 0 ~ 5. (0:0.01, 1:0.1, 2:1, 3:10, 4:100, 5:1000)
- DATA9 (MOD-BUS ADDRESS 40010) : not used
- DATA10 (MOD-BUS ADDRESS 40011) : not used
- DATA11 (MOD-BUS ADDRESS 40012) : Set display speed of total count accumulated value
 - Range is 0.1~19.9 sec., and one should send by multiplying 10 when transmitting the value.
- DATA 12 (MOD-BUS ADDRESS 40013) : Set RS485 Communication address
 - Range is 1 ~ 255.
- DATA 13 (MOD-BUS ADDRESS 40014) : Set RS485 COMMUNICATION SPEED
 - Range is 0 ~ 5.
(0 : 2400bps, 1 : 4800bps, 2 : 9600bps, 3 : 19200bps, 4 : 38400bps, 5 : 57600bps)
- ※ Be careful as it can't be communicated when transmitting incorrectly the communication address and communication speed.
- DATA14 (MOD-BUS ADDRESS 40015) : Not used
- DATA15 (MOD-BUS ADDRESS 40016) : Reset total count accumulated value
 - If transmitting 1 to Address 40016, one can reset total count accumulated value.

◆ SAVE OF 2 WORD DATA

KC-2600 ADDR	FUNCTION CODE	ADDR H	ADDR L	CHANNEL H	CHANNEL L	BYTE SIZE
1~255	10H	0010H or 0012H or 0014H or 0016H or 0018H		02H		04H

DATA LH	DATA LL	DATA HH	DATA HL	CRC H	CRC L
0010H or 0012H or 0014H or 0016H or 0018H				CRC 16	



- FLUX LOW SCALE, HIGH SCALE, ANALOG OUTPUT LOW RANGE, HIGH RANGE, TOTAL COUNT accumulated value parameter correspond to it.
 - FUNCTION CODE : 10H (Holding register 03H of MOD-BUS memory function)
 - ADDR H, ADDR L : START ADDRESS of set PARAMETER
 - 0010H = START ADDRESS of flux LOW SCALE (MOD-BUS Address 40017, 40018)
 - 0012H = START ADDRESS of flux HIGH SCALE (MOD-BUS Address 40019, 40020)
 - 0014H = START ADDRESS of ANALOG output LOW RANGE (MOD-BUS ADDRESS 40021, 40022)
 - 0016H = START ADDRESS of ANALOG output HIGH RANGE (MOD-BUS ADDRESS 40023, 40024)
 - 0018H = START ADDRESS of TOTAL COUNT accumulated value (MOD-BUS Address 40025, 40026)
 - CHANNEL H, CHANNEL L : Fix to 02H as it's 2 WORD
 - BYTE SIZE : Fix to 04H as it's BYTE SIZE : 4 BYTE DATA
 - DATA 16, 17 (MOD-BUS ADDRESS 40017, 40018) : Set the FLUX LOW SCALE value
 - Range is 0 ~ 99999, and it should be transmitted with value not having decimal point.
 - DATA18, 19 (MOD-BUS ADDRESS 40019, 40020) : Set up flux HIGH SCALE value.
 - Range is 0 ~ 99999, and it should be transmitted with value not having decimal point.
 - DATA20, 21 (MOD-BUS ADDRESS 40021, 40022) : Set up ANALOG output LOW RANGE.
 - Range is 0 ~ 99999, and it should be transmitted with value not having decimal point.
 - DATA22, 23 (MOD-BUS ADDRESS 40023, 40024) : Set up ANALOG output HIGH RANGE.
 - Range is 0 ~ 99999, and it should be transmitted with value not having decimal point.
 - DATA24, 25 : Set up TOTAL COUNT accumulated value.
 - Range is 0 ~ 1999999999, and it should be transmitted with value not having decimal point.
- ※ Even number DATA is the LOW WORD of value, and odd number DATA is HIGH WORD of value.



Chapter 4 Troubleshooting and Repair

Troubleshooting the Flow Meter

Begin hardware troubleshooting by verifying the following facilities issues are correct. These areas impact system operation and must be corrected prior to performing any flow meter inspections.

1. Verify the incoming power to the flow meter is present and of the correct voltage and polarity.
2. Check the flow meter wiring for correct connections as described in Chapter 2.
3. Verify the flow meter is installed with the correct number of upstream and downstream pipe diameters as shown on page 9
4. Verify the flow direction indicator is correctly aligned pointing downstream of flow.
5. Make sure there are no leaks in the line being measured.

※ After verifying the factors above, follow the troubleshooting procedures outlined on the next page. If you need to return the flow meter to the factory, see page 28 for return shipping instructions.



Caution!

Before attempting any flow meter repair, verify that the line is not pressurized.



Caution!

Always remove main power before disassembling any part of the mass flow meter.

Symptom	possible causes	measure
Flow rate measurement value is wrong or fluctuates too much	Abnormal flow	Refer to chapter.2 Installation conditions
	The front and rear pipe diameters of the sensor are smaller than required specification	Refet to chapter.2 installation conditions
	Insertion sensor is not securely fastened	Secure the sensor firmly in place without vibration.
	The constituent parts of the sensor are damaged	Exchange od repair
	Failure if electronic caution	Exchange od repair
	Bad ground	Refer to chapter.2 wiring
	Moisture in gas	Install moisture eliminator of filler at the front end of the sensor
Measured value is too high or low	Sensor is not installed correctly in the direction of fluid flow	Sensor is installed with the momitor facing front
	Sensor not inserted at the correct depth	Set the measuring point to be in the center of the pipe
No response from the sensor	The power is off	Switch on power
	The low-speed removal value was set too high (FLO SPD cut 0.1m/s)	Correctly reset lpw-speed removal function
	Exceeds low flow measurement limit below instrument minimum measurement range	Factory inquiry Set the user setting range equal to the manufacturing setting range Expand the piping to below the maximum the measuring range of the meter nameplate or inquire at factory
No pulse output	Relay coil insufficient current capacity	Relay coil current should be within 25mA maximum relay
	Torsion of instrument appearance	Relocate installation to another installation location
	several vortex flow	Setup separate blower or idle mixer or valve near instrument
Self diagnosis function sensor and sensor board When detects PCB failure	Sensor failure BAD substrate (MODE lamp flashing red)	Replace ield after confirming fault Check for sensor failure (RH and GND = 48Ω) (RH and GND =1280Ω) Check factory repair board fault (Display not directed)

GAS FACTOR TABLE 1

Gasname	Formula	Gasfactor	Orifice factor	Density (kg/m ³)
Acetylene (Ethyne)	C ₂ H ₂	0,615	0,970	1,173
Air	Mixture	0,998	1,018	1,293
Allene	C ₃ H ₄	0,478	1,199	1,787
Ammonia	NH ₃	0,786	0,781	0,771
Argon	Ar	1,395	1,195	1,784
Arsine	AsH ₃	0,754	1,661	3,478
Boron Trichloride	BCL ₃	0,443	2,044	5,227
Boron Trifluoride	BF ₃	0,579	1,569	3,025
Bromine Pentafluoride	BrF ₅	0,287	2,502	7,806
Bromine Trifluoride	BrF ₃	0,439	2,214	6,108
Bromotrifluoroethylene	C ₂ BrF ₃	0,326	2,397	7,165
Bromotrifluoromethane (f-13B1)	CBrF ₃	0,412	2,303	6,615
1,3-Butadiene	C ₄ H ₆	0,354	1,413	2,491
Butane	C ₄ H ₁₀	0,257	1,467	2,593
1-Butene	C ₄ H ₈	0,294	1,435	2,503
CIS-2-Butene	C ₄ H ₈	0,320	1,435	2,503
Trans-2-Butene	C ₄ H ₈	0,291	1,435	2,503
Carbon Dioxide	CO ₂	0,773	1,255	1,977
Carbon Disulfide	CS ₂	0,638	1,650	3,393
Carbon Monoxide	CO	0,995	1,000	1,250
Carbon Tetrachloride	CCL ₄	0,344	2,345	6,860
Carbon Tetrafluoride (f-14)	CF ₄	0,440	1,770	3,926
Carbonyl Fluoride	COF ₂	0,567	1,555	2,045
Carbonyl Sulfide	COS	0,680	1,463	2,680
Chlorine	CL ₂	0,876	1,598	3,214
Chlorine Dioxide	CLO ₂	0,693	1,554	3,011
Chlorine Trifluoride	CLF ₃	0,433	1,812	4,125
Chlorodifluoromethane (f-22)	CHCLF ₂	0,505	1,770	3,906
Chloroform (Trichloromethane)	CHCL ₃	0,442	2,066	5,340
Chloropentafluoroethane (f-115)	C ₂ CLF ₅	0,243	2,397	7,165
Chlorotrifluoroethylene	C ₂ CLF ₃	0,337	2,044	5,208
Chlorotrifluoromethane (f-13)	CCLF ₃	0,430	1,985	4,912
2-Chlorobutane	C ₄ H ₉ CL	0,234	1,818	4,134
Cyanogen	(CN) ₂	0,498	1,366	2,322
Cyanogen Chloride	CLCN	0,618	1,480	2,730
Cyclobutane	C ₄ H ₈	0,387	1,413	2,491

GAS FACTOR TABLE 2

Gasname	Formula	Gasfactor	Orifice factor	Density (kg/m ³)
Cyclopropane	C ₃ H ₆	0,505	1,224	1,877
Deuterium	D ₂	0,995	0,379	0,177
Diborane	B ₂ H ₆	0,448	1,000	1,235
Dibromodifluoromethane (f-12B2)	CBr ₂ F ₂	0,363	2,652	8,768
1,2-Dibromotetrafluoroethane (f-114B2)	C ₂ Br ₂ F ₄	0,215	2,905	10,530
Dichlorodifluoromethane (f-12)	CCl ₂ F ₂	0,390	2,099	5,492
Dichlorofluoromethane (f-21)	CHCl ₂ F	0,456	1,985	4,912
Dichlorosilane	SiH ₂ Cl ₂	0,442	1,897	4,506
Diedthylsilane	C ₄ H ₁₂ Si	0,183	1,775	3,940
2,2 Dichloro- 1,1,1- Trifluoroethane	C ₂ HCl ₂ F ₃	0,259	2,336	6,829
1,2-Dichloroethane (Ethylene dichloride)	C ₂ H ₄ Cl ₂	0,382	1,879	4,419
1,2-Dichlorotetrafluoroethane (f-114)	C ₂ Cl ₂ F ₄	0,231	2,449	7,479
1,1-Difluoro-1-Chloroethane	C ₂ H ₃ ClF ₂	0,341	1,957	4,776
1,1-Difluoroethane	CH ₃ CHF ₂	0,415	1,536	2,940
1,1-Difluoroethylene	CH ₂ :CF ₂	0,458	1,512	2,860
Difluoromethane (f-32)	CF ₂ H ₂	0,627	1,360	2,411
Dimethylamine	(CH ₃) ₂ NH	0,370	1,269	2,013
Dimethylether	(CH ₃) ₂ O	0,392	1,281	2,055
2,2-Dimethylpropane	C(CH ₃) ₄	0,247	1,613	3,244
Disilane	Si ₂ H ₆	0,332	1,493	2,779
Ethane	C ₂ H ₆	0,490	1,038	1,357
Ethanol	C ₂ H ₆ O	0,394	1,282	2,057
Ethylacetylene	C ₄ H ₆	0,365	1,384	2,388
Ethyl Chloride	C ₂ H ₅ Cl	0,408	1,516	2,879
Ethylene	C ₂ H ₄	0,619	1,000	1,261
Ethylene Oxide	C ₂ H ₄ O	0,589	1,254	1,965
Fluorine	F ₂	0,924	1,163	1,695
Fluoroform (f-23)	CHF ₃	0,529	1,584	3,127
Germane	GeH ₄	0,649	1,653	3,418
Germanium Tetrachloride	GeCl ₄	0,268	2,766	9,574
Halothane	C ₂ HBrClF ₃	0,257	2,654	8,814
Helium	He	1,386	0,378	0,178
Hexafluoroacetone	C ₃ F ₆ O	0,219	2,434	7,414
Hexafluorobenzine	C ₆ F ₆	0,632	2,577	8,309
Hexafluoroethane (f-116)	C ₂ F ₆	0,255	2,219	6,139
Hexafluoropropylene (HFP)	C ₃ F ₆	0,249	2,312	6,663

GAS FACTOR TABLE 3

Gasname	Formula	Gasfactor	Orifice factor	Density (kg/m ³)
Hydrogen	H ₂	1.008	0.269	0.090
Hydrogen Bromide	HBr	0.987	1.695	3.645
Hydrogen Chloride	HCL	0.983	1.141	1.639
Hydrogen Cyanide	HCN	0.744	0.973	1.179
Hydrogen Fluoride	HF	0.998	0.845	0.893
Hydrogen Iodide	HI	0.953	2.144	5.789
Hydrogen Selenide	H ₂ Se	0.837	1.695	3.613
Hydrogen Sulfide	H ₂ S	0.850	1.108	1.539
Iodine Pentafluoride	IF ₅	0.283	2.819	9.907
Isobutane	C ₄ H ₁₀	0.260	1.440	2.596
Isobutene	C ₄ H ₈	0.289	1.435	2.503
Isopentane	C ₅ H ₁₂	0.211	1.605	3.222
Krypton	Kr	1.382	1.729	3.708
Methane	CH ₄	0.763	0.763	0.717
Methylacetylene	C ₃ H ₄	0.473	1.196	1.782
Methyl Bromide	CH ₃ Br	0.646	1.834	4.236
3-Methyl-1-butene	C ₅ H ₁₀	0.252	1.584	3.127
Methyl Chloride	CH ₃ CL	0.687	1.347	2.308
Methyl Fluoride	CH ₃ F	0.761	1.102	1.518
Methyl Mercaptan	CH ₄ S	0.588	1.313	2.146
Methyl Silane	CH ₆ Si	0.393	1.283	2.061
Methyl Trichlorosilane	CH ₃ CL ₃ Si	0.267	2.310	6.675
Methyl Vinyl Ether	C ₃ H ₆ O	0.377	1.435	2.567
Monoethylaniline	C ₂ H ₇ NO	0.305	1.477	2.728
Monoethylamine (CH ₃ CH ₂ NH ₂)	C ₂ H ₇	0.359	1.269	2.013
Monomethylamine	CH ₃ NH ₂	0.565	1.047	1.420
Neon	Ne	1.398	0.847	0.902
Nickel Carbonyl	Ni(CO) ₄	0.212	2.371	7.008
Nitric Oxide	NO	0.995	1.030	1.339
Nitrogen	N ₂	1.000	1.000	1.251
Nitrogen Dioxide	NO ₂	0.758	1.713	2.052
Nitrogen Trifluoride	NF ₃	0.501	1.598	3.168
Nitrogen Trioxide	N ₂ O ₃	0.443	1.649	3.389
Nitrosyl Chloride	NOCL	0.644	1.529	2.913
Nitrous Oxide	N ₂ O	0.752	1.259	1.964
Octofluorocyclobutane	C ₄ F ₈	0.169	2.678	8.933
Oxygen	O ₂	0.988	1.067	1.429

GAS FACTOR TABLE 4

Gasname	Formula	Gasfactor	Orifice factor	Density (kg/m ³)
Oxygen Difluoride	OF ₂	0,672	1,388	2,402
Ozone	O ₃	0,738	1,310	2,138
Perchloryl Fluoride	CLO ₃ F	0,448	1,905	4,571
Perfluorobutane	C ₄ F ₁₀	0,738	2,918	10,610
Perfluoro-2-Butene	C ₄ F ₈	0,268	2,672	8,933
Perfluoromethyl-vinylether (PMVE)	PMVE	0,296	2,029	5,131
Perfluoropropane	C ₃ F ₈	0,179	2,591	8,396
Pentane (n-Pentane)	C ₅ H ₁₂	0,212	1,605	3,222
Pentafluoroethane	C ₂ HF ₅	0,287	2,070	5,360
Phosgene	COCL ₂	0,504	1,881	4,418
Phosphine	PH ₃	0,783	1,100	1,517
Phosphorous Pentafluoride	PF ₅	0,346	2,109	5,620
Phosphorous Trifluoridide	PF ₃	0,495	1,770	3,906
Propane (same as CH ₃ CH ₂ CH ₃)	C ₃ H ₈	0,343	1,274	2,008
Propylene (Propene)*	C ₃ H ₆	0,401	1,234	1,875
Rhenium Hexafluoride	ReF ₆	0,230	3,279	13,410
Silane	SiH ₄	0,625	1,070	1,440
Silicon Tetrachloride	SiCL ₄	0,310	2,462	7,579
Silicon Tetrafluoride	SiF ₄	0,395	1,931	4,648
Sulfur Dioxide	SO ₂	0,728	1,529	2,858
Sulfur Hexafluoride	SF ₆	0,270	2,348	6,516
Sulfur Tetrafluoride	SF ₄	0,353	1,957	4,776
Sulfur Trioxide	SO ₃	0,535	1,691	3,575
Sulfuryl Fluoride	SO ₂ F ₂	0,423	1,931	4,648
Tetrachloromethane	CCL ₄	0,344	2,345	6,858
Tetrafluoroethylene (TFE)	C ₂ F ₄	0,361	1,905	4,526
Tetrafluorohydrazine	N ₂ F ₄	0,367	1,926	4,624
Trichlorofluoromethane (f-11)	CCL ₃ F	0,374	2,244	6,281
Trichlorosilane	SiHCL ₃	0,329	2,201	6,038
Trimethyloxyborane (TMB)	B(OCH ₃) ₃	0,300	1,929	4,638
1,1,2-Trichloro-1,1,2-Triflouroet (f-113)	C ₂ CL ₃ F ₃	0,231	2,520	7,920
Trimethylamine	(CH ₃) ₃ N	0,316	1,467	2,639
Tungsten Hexafluoride	WF ₆	0,227	3,264	13,280
Uranium Hexafluoride	UF ₆	0,220	3,548	15,700
Vinyl Bromide	C ₂ H ₃ Br	0,524	1,985	4,772
Vinyl Chloride	C ₂ H ₃ CL	0,542	1,492	2,788
Vinyl Fluoride	C ₂ H ₃ F	0,576	1,281	2,046
Water Vapor	H ₂ O	0,861	0,802	0,804
Xenon	Xe	1,383	2,180	5,851

Gas & Liquid type THERMAL MASS FLOW METER
Specialty Manufacture Company

GOLDEN RULES



Golden Rules Co., Ltd

Smart valley A-1805, SONGDOMIRAE-RO30, Yeonsu-gu, Incheon,
Korea

TEL:+82-32-817-1240

FAX:+82-32-817-1250

E-mail: hhm617@hanmail.net

<http://www.goldenrules.co.kr>

