

KC-8860 Electromagnetic Flowmeter Converter

User's Manual

KC-8860 Series



GOLDEN RULES CO., LTD.

Smart valley A-1805, Songdo Mirae-Ro 30,
Yeonsu-gu, Incheon, Korea

TEL:+82-32-817-1240

FAX:+82-32-817-1250

E-mail:hhm617@hanmail.net

<http://www.goldenrules.co.kr>

www.kcmass.co.kr

CONTENTS

1. The product function introduction	- 1 -
1.1 Basic function	- 1 -
1.2 Normal operating conditions.....	- 1 -
2. KC-8860 Exterior Size and Power Connection Instruction	- 2 -
2.1 Exterior Size:	- 2 -
2.2 CFM Power Supply Connection	- 3 -
2.3 Output Signal Terminal Connection.....	- 3 -
2.3.1 Current Output	- 3 -
2.3.2 Sensor Signal Connection:	- 5 -
3.Operation Converter	- 6 -
3.1 Key and Display.....	- 6 -
3.2 Menu Structure.....	- 7 -
3.2.1 Select Menu	- 9 -
4. Parameter Set and Use	- 10 -
4.1.Zero Trim	- 10 -
4.1.1Quick Zero Trim	- 10 -
4.1.2 Zero Trim in the process of flowmeter calibration.....	- 11 -
4.2 Fast Setting	- 12 -
4.3 (BAS) Setting.....	- 12 -
4.3.1 Damping(s)	- 12 -
4.3.2 PV Decimal	- 12 -
4.3.3 Total decimal.....	- 13 -
4.3.4 LCD Rotate	- 13 -
4.4 (SYS)Setting	- 13 -
4.4.1 Qmax (m ³ /h)	- 13 -
4.4.2 Low Cutoff (%).....	- 13 -
4.4.3 Max Limit (%)	- 13 -
4.4.4 Limit Time(s)	- 14 -
4.4.5 Direction	- 14 -
4.4.6 Indication	- 14 -
4.4.7 Pulse Output.....	- 14 -
4.4.8 Modbus Output	- 15 -
4.4.9 Clear Total.....	- 16 -
4.4.9(II)Load settings	- 16 -
4.5 TRIM	- 16 -
4.5.1 Tube Trim.....	- 16 -
4.5.2 Loop Trim	- 17 -
4.5.3 Zero Trim	- 17 -
4.5.5 TOTAL.....	- 17 -
4.6 CHK.....	- 18 -
4.6.1 Loop Test.....	- 18 -

4.6.2 Pulse Test	- 18 -
5. Self-diagnosis Information and fault handling.....	- 18 -
5.1 Fault handling	- 18 -
5.1.1 No display on the screen	- 18 -
5.1.2 Excitation Alarm	- 18 -
5.1.3 Empty Alarm.....	- 18 -
5.1.4 Inaccuracy	- 19 -
6.Password Setup	- 18 -

KC-8860 Electromagnetic Flowmeter Converter Instruction Manual

1. The product function introduction

1.1 Basic function



- Executive Standard: JB/T9248-1999 GB 3836.1-2010
GB 3836.2-2010 GB 3836.4-2010
- Current speed range: 0.03m/s~12m/s
- Repeatability: $\pm 0.1\%$
- Display
English displaying mode can display the instantaneous flow, the percentage of flow, the total forward flow and reverse flow
- Output signal:
Analog output:4~20mA Load resistance: $<750\Omega$
Frequency: 0~5kHz 24V
Pulse
RS485 communication
HART (selectable)
- Excitation mode
Three amplitude low frequency excitation
High frequency excitation
- Excitation Frequency
1/16、1/8、1/4、1/2 can be set
- Excitation Electricity
160mA or specified
- Time Constant
0.1~99.9 Second can be set
- Ex-proof Mark
Exd[ia]iaICT5

1.2 Normal operating conditions


- Ambient Temperature Ranges: $-20^{\circ}\text{C} \sim +55^{\circ}\text{C}$
- Relative Humidity:5%~90%
- Power supply: 85~265AC or 18~36VDC Active
- Power consumption: <10W

2. KC-8860 Exterior Size and Power Connection Instruction

2.1 Exterior Size



2.2 KC-8860 Power Supply Connection



Note: When connect power wires, please confirm the power supply type first. Please never insert AC power to DC converter. If connection wrong, it'll permanent damage the converter!

KC-8860 Power Connection Instruction

NO.	Mark	Function	Remark
L	L	AC 85~265v Power supply	L is for Ac220v Power supply
N	N	AC 85~265v Power supply	N is for Ac220v Power supply
+	+	DC 18~36v Power supply+	DC 24v +
-	-	DC 18~36v Power supply-	DC 24v -

2.3 Output Signal Terminal Connection




2.3.1 Current Output


Instruction:

- a) Analog output signal connection: 4~20mA, Max load resistance:500Ω
- b) Pulse Output Connection: Frequency:0~5kHz, V value:24V, Load current:50mA

Note1: When connect output signal wire, please note the function of insertion cable. (eg. Electricity Frequency or Communication). Please definitely distinguish the output type (eg. Active output or Passive output)

Note2: When connection the wire, please never connect the power to the output terminal. Or else it may permanent damage the converter!






CFM Power Connection Terminal Instruction

NO.	Mark	Function	Remark
1	+	4~20mA Output +	Load Resistance $\leq 500\Omega$ When use Hart communication, please use Exterior Power 24VDC
2	-	4~20mA Output -	
3	+	Frequency or Pulse Output +	The Amplitude of Frequency or Pulse output is +24v, Load current $\leq 50\text{mA}$
4	-	Frequency or Pulse Output -	
5	+	RS-485 Data +	
6	-	RS-485 Data -	

2.3.2 Sensor Signal Connection:




Note: When connect sensor signal, please don't mixed the signal wire A B C and the Excitation wire X Y. If connection wrong, it'll damage the converter permanent.

CFM Excitation and Input Signal Connection Terminal Instruction


NO.	Mark	Function	Remark
1	X	Excitation X	Load Resistance 10~100Ω
2	Y	Excitation Y	
3	A	Input signal A	
4	C	Input signal common terminal	
5	B	Input signal B	

3.Operation Converter



3.1 Key and Display



- Parameter Confirm and Exit the submenu (Left shift key)
- Shift down and data decrease key (Shift down key)
- Right shift key




Shortcut Key& Combination Key

- and System Zero Point Calibration Press then press
- and Combination, you can quickly choose 'instantaneous flow unit', 'accumulative total flow direction' and 'accumulative total flow unit'. First press choose 'setting' then press to change parameters and then please press to save and Exit
- Press or can set increase or decrease of the LCD display construct

3.2 Menu Structure





3.2.1 Select Menu

3.2.1.1 Parameter Set in Measuring Mode

- Press “C/CE” key,it’ll show as picture in right

- Choose“C/CE”to enter the menu:


(BAS)

(SYS)

(TRIM)


(CHK)

- Press“→” to ESC.




3.2.1.2 (BAS) Menu

- Damping(s) (0.1~99.1)
- PV Decimal (1、 2、 3)
- Total Decimal (1、 2、 3)
- LCD Rotate (0、 +90、 180、 -90)




3.2.1.3 (SYS) Menu

- Signal
- \ Pulse Output
- MODBUS Output
- Clear Total
- Load Settings




3.2.1.4 (TRIM) Menu

- Tube Trim
- Loop Trin
- Zero Trim
- K Character
- TOTALPRESET



3.2.1.5 (CHK) Menu

- Loop Test
- Pulse Test



4. Parameter Set and Use

4.1. Zero Trim


When use electromagnetic flowmeter, should do Zero Trim in order to get accurate measure result.

“Zero Trim” means to adjust the working Zero point when set current actual flow as Zero. While doing Zero Trim, please make sure the medium is static and full of the measuring tube.

4.1.1 Quick Zero Trim


- Condition: the measuring tube is full of medium and medium is static
- Press “↓” and then “→”, the converter come to Zero Trim Program

LCD display as:




- If Press “→”, Converter will cancel Zero Trim Mode and exit to Measuring Mode.

If Press “C/CE”, Converter come to Zero Trip Mode and will display as:



- After Zero Trim, Converter will automatically come back to Measure Mode.





4.1.2 Zero Trim in the process of flowmeter calibration

- Condition: the measuring tube is full of medium and medium is static
First come to 'Zero Trim':



- Press 'C/CE', then also press 'C/CE',
enter set up as Picture 1 in right:

- Press '→', choose 'TRIM'
Press '↓' to 'Zero Trim' as picture 2
Press '→' as picture 3




- Press '→' or '↓', choose 'yes'
Press '→' enter to picture 4




Zero Trim Picture 4

- Press 'C/CE', come to 'Zero Trim' double confirm as picture 5
If press '→', will exit 'Zero Trim'.
'Zero Trim' double confirm interface as picture 5
Choose 'C/CE', will execute 'Zero Trim'
Choose '→' will exit 'Zero Trim'



Zero Trim Picture 5

- Execute 'Zero Trim' as Picture 6
After adjust zero point, converter
Will come back to measure mode.



Zero Trim Picture 6

4.2 Fast Setting


■ Flow Unit



Parameter type: Choose


Default Value: m³/h

Range: L/s L/m L/h m³/s m³/m

m³/h G/s G/m G/h

Press  to choose 'setting',

Press  to choose flow unit then press  to exit






(2) Total flow Unit


Parameter type: Choose

Default Value: m³

Range: L m³ G

Press  to choose 'setting'

Press  to choose flow unit then press  to exit






(3) Accumulative total flow Direction


Parameter type: Choose

Default Value: TOTAL+

Range: TOTAL+, TOTAL-

Press  to choose 'setting'

Press  to choose flow unit then press  to exit




4.3 (BAS) Setting




4.3.1 Damping(s)

■ Parameter type: fix-point decimal

Default value: 1.0

Range: 99.9 – 0.1




Press  to choose 'setting' Press  to change damping time, Press  to exit.

4.3.2 PV Decimal

■ Parameter type: Choose


Default value: 1.0

Range: 1, 2, 3




4.3.3 Total decimal

- Parameter type: Choose
- Default value: 1.0
- Range: 1、2、3



4.3.4 LCD Rotate


- Parameter type: Choose
- Default value: 0
- Range: +90、180、-90



4.4 (SYS)Setting

4.4.1 Qmax (m3/h)

- Parameter type: Floating-point Decimal
- Default value: 100.0
- Range: m – n



Scale flow range max m: flow rate at 15m/s in current diameter
 Scale flow range min n: flow rate at 0.1m/s in current diameter

$$m = (D * D) / 23.6 \quad D - \text{diameter(mm)}$$

$$n = (D * D) / 3540.0$$


Scale flow means when flow achieve setting value, current output is 20mA, pulse output is the setting value in 'Pulse output'. If change this parameter, it'll impact the current output and pulse output.

4.4.2 Low Cutoff (%)

- Parameter type: Fix-point decimal
- Default value: 0.0
- Range: 9.9 – 0.0


e.g: if scale flow=100m3/h
 Low cutoff=1.0%

Then, when instantaneous flow < 1m3/h, it'll be cutoff



4.4.3 Max Limit (%)

- Parameter type: Fix-point decimal
- Default value: 0.0
- Range: 9.9 – 0.0



e.g: if setting value is 1%,the display and output value will compress fluctuation value to 1% in the limit time period.

4.4.4 Limit Time(s)


Parameter type: Fix-point decimal

Default value: 00.0

Range: 99.9 – 0.0

eg: if setting value is 7s, the display and output

Will compress fluctuation value to max limit 1% within 7s.



4.4.5 Direction


Parameter type: Choose

Default value: Forward

Range: Forward Reverse

If set as forward,, reverse flow will not be calculate and display

If set as bi-direction,forward flow and reverse flow will both be calculate and display.



4.4.6 Indication


Parameter type: Choose

Default value: Forward

Range: Forward Reverse

If set as forward, reverse flow will be calculate and display as forward direction.

If set as reverse,forward flow will be calculate and display as reverse direction.



4.4.7 Pulse Output


4.4.7.1 Freq Max (Hz)

■ Parameter type: fix-point decimal

Default value: 2000.0

Range: 5000.0 – 100.0

Current Frequency(Hz) = (Current flow(m3/h)/scale flow(m3/h))*Frequence max(Hz)




4.4.7.2 Liter/Pulse

■ Parameter type: floating-point decimal

Default value: 0.0

Range: m – 0.00555



$$\text{Output frequency(Hz)} = \frac{\text{Current flow(m}^3\text{/h)} / 3.6}{\text{Pulse(L/P)}} = \frac{\text{current flow (L/s)}}{\text{Pulse(L/P)}}$$

Frequency Range: 10000.0 – 0.006Hz

If exceed this period, it'll output the corresponding limit value.

When pulse = 0.0 ,frequency output depends on “frequency max”setting

When pulse >0.0, frequency output depends on “Liter/Pulse” setting


4.4.7.3 Pulse Width (ms)

■ Parameter type: floating-point decimal

Default value: 0.0000

Range: 0.1000 – 0.0000

If is default value,output pulse duty-cycle is 1:1.




4.4.8 Modbus Output

4.4.8.1 Protocol

■ Parameter type: Choose

Default value: RTU

Range: RTU、ASC




4.4.8.2 Baud rate

■ Parameter type: Choose

Default value: 9600

Range: 1200 2400 4800 9600 communication rate




4.4.8.3 Parity

■ Parameter type: Choose

Default value: None

Range: None/ODD/Even




4.4.8.4 Dev Address

■ Parameter type: Number

Default value: 001


Range: 999 – 001



4.4.9 Clear Total

- Parameter type: Choose
- Default value: No
- Range: No Yes


This setting will make forward and reverse total flow return to zero.



4.4.9(II) Load settings

- Parameter type: Choose
- Default value: No
- Range: No Yes

If choose yes, it'll restore factory parameter settings.




4.5 TRIM

4.5.1 Tube Trim

4.5.1.1 Empty Trim

- Parameter type: Choose
- Default value: No
- Range: No Yes


Make sure measuring tube is empty. When execute this function, flowmeter will automatically record the characteristic value in empty tube.



4.5.1.2 Full TRIM

- Parameter type: Choose
- Default value: No
- Range: No Yes


Make sure measuring tube is full. Execute this function, flowmeter will automatically record the characteristic value in full tube.



4.5.1.3 Tube Region (%)

- Parameter type: fix-point decimal
- Default value: 0.0
- Range: 99.9—0.0

The value of Tube Region is bigger means that empty tube region is more sensitive.




4.5.2 Loop Trim

4.5.2.1 4mA Trim

- Parameter type: fix-point decimal
- Default value: 4.0000
- Range: 5.000 – 3.000

When execute this function, and use accurate ampere meter to measure 4-20mA output. Input the reading value to the converter, and converter will automatically achieve trim work.




4.5.2.2 20mA Trim

The same as 4.5.2.1

4.5.3 Zero Trim


- Parameter type: Choose
- Default value: No
- Range: No Yes

Make sure the measuring tube is full and medium is static. After fully preheat, execute this function then the flowmeter will automatically do Zero Trim.



4.5.4 K Character


- Parameter type: fix-point decimal
- Default value: 1.0000
- Range: 0.970000 ~ 1.030000




4.5.5 TOTAL

This function is used to modify the accumulative total flow.

4.5.5.1 Total + (m3/h)



4.5.5.2 Total - (m3/h)




4.6 CHK

4.6.1 Loop Test

- Parameter type: fix-point decimal
Default value: 12.0
Range: 20.0 – 4.0

Execute this function and use accurate ampere meter to measure 4~20mA current output.

Change present set value in the allowed range to test the deviation between output value and set value.




4.6.2 Pulse Test

- Parameter type: fix-point decimal
Default value: 1000.0
Range: 5000.0 – 1.0

Execute this function and use accurate cymometer to measure frequency output.

Change present set value in the allowed range to test the deviation between output value and set value.



5. Self-diagnosis Information and fault handling

Electromagnetic flowmeter converter have self-diagnosis function. It can provide correct alarm information by itself for most general fault except power supply and hardware circuit fault. Fault Information will display in the bottom right of the LCD screen.

5.1 Fault handling

5.1.1 No display on the screen

- Check whether the power supply is switched on
- Check whether the power fuse is intact
- Check whether the power supply voltage is conform to the requirements

If above information is normal, please contact with manufacturer.

5.1.2 Excitation Alarm

- Check whether the Excitation line X and Y are open circuit
- Check whether the Excitation coil resistance is normal, or else it means that converter may has fault.

5.1.3 Empty Alarm

- Check if the liquid medium is full of measuring tube
- Use wire to make signal input terminal A,B and C short circuit. At this moment if 'Empty Alarm' indicate revocation, it means that converter is normal. This fault may caused by low

conductivity of measuring medium or the setup error of empty tube threshold value and empty tube measuring range.

- c) Check whether signal line connection are correct
- d) Check whether sensor electrodes are normal


5.1.4 Inaccuracy



- a) Check whether the liquid is full of the measuring tube
- b) Check whether the signal line connection are normal
- c) Check whether the sensor coefficient,zero point is normal or Calibration setting is normal.

6. Password Setup


■ Enter Detail Setup Interface

1. Long Press“C/CE”for more than 5 seconds,then enter detail setup interface:



2. Press the second key  , then press  to choose YES to enter DETAIL SETUP Interface.

■ Change Password


1. Press  to enter “NEW PASSWORD”

2. Press   to change the password.

Note:Ex-factory password is 4000.

3. Press  to save the settings.

- Return to the normal measure interface

After “Save Settings”, long press  for more than 5 seconds to return to the normal measure Interface as below:

